


**Priključne letve**  
Distribution manifolds


## PRIKLJUČNE LETVE / DISTRIBUTION MANIFOLDS

**VB**




Navoj Thread [A]	Tip Type	d [mm]	L [mm]	L3 [mm]	C [mm]
G1/8	VB-18	4,5	25	4,3	15
G1/4	VB-14	5,5	40	6,5	20
G3/8	VB-38	5,5	50	7,5	25
G1/2	VB-12	5,5	50	7,5	30

**FR4**



Navoj Thread [A]	Tip Type	n	Navoj Thread [G]	d [mm]	L [mm]	L1 [mm]	L2 [mm]	L3 [mm]	L4 [mm]	L5 [mm]	C [mm]	D [mm]
G1/8	FR4-18	3	1/8	4,4	56	17	13,5	46	12	11,6	20	20
G1/4	FR4-14	3	1/4	6,4	89	29	20	74	16	17	30	30
G3/8	FR4-38	3	3/8	6,4	85	26	20	72	25	19	32	26
G1/2	FR4-12	3	1/2	6,4	105	32	25	90	24	23	40	30

**FR**



Navoj Thread [A]	Tip Type	n	Navoj Thread [G]	d [mm]	L [mm]	L1 [mm]	L2 [mm]	C [mm]	D [mm]
G1/4	FR 183	3	1/8	4,5	95	30	17,5	18	24
	FR 184	4	1/8	4,5	125	30	17,5	18	24
	FR 185	5	1/8	4,5	155	30	17,5	18	24
	FR 186	6	1/8	4,5	185	30	17,5	18	24
G3/8	FR 143	3	1/4	5,5	112	36	20	22	30
	FR 144	4	1/4	5,5	148	36	20	22	30
	FR 145	5	1/4	5,5	184	36	20	22	30
	FR 146	6	1/4	5,5	220	36	20	22	30
G1/2	FR 383	3	3/8	5,5	130	40	25	26	35
	FR 384	4	3/8	5,5	170	40	25	26	35
	FR 385	5	3/8	5,5	210	40	25	26	35
	FR 386	6	3/8	5,5	250	40	25	26	35